

Bluetooth Module Software Update Procedure

You are now ready to begin the update.

Insert the Bluetooth dongle into an available USB port on your PC.

Bluetooth Software Update Guide (Part 2)

To begin the Bluetooth Module Software Update, you will need to firstly initiate Your Kenwood Audio Product for the update and secondly launch to Parrot Software Update Wizard saved on your PC (see Part 1).

Note: Please be advised that the settings on Your Kenwood Audio Product will be cleared further to completing the Software Update, i.e. Paired Phones, User Settings, Voice Tags.

Initiate Your Kenwood Audio Product for the Update Process

Complete the following steps.

(Note: for multimedia units refer to column left; for head units refer to column right.)




Select STANDBY in the Source menu.



Select STANDBY.



Press [FNC] button to enter the Menu.



Press [SETUP] / [Software Information].



Select [BT FW Update].



Press the [START] button.



"WAITING" will be displayed.



Press and hold the Control Knob.



Select [Yes] and press the Control Knob.



"Update Ready" will be displayed.

Initiate Your Kenwood Audio Product for the Update Process #2

(Note: head units)



Select Standby.



Press [FNC] button to enter the Menu.





Select [BT F/W Update].




Press and hold the Control Knob.



Launching the Software Update Tool


The Parrot Software Update Wizard will likely be located in **All Programs** under the **Start** button on the bottom left of your PC screen.



Launch the Parrot Update Wizard by selecting [Start] > [All Programs] > [Parrot Software Update Tool] > [Parrot Flash Update Wizard].




Select [Next].




Select [Next].

Note: In the “Choose a device type” screen, CK505X will be the only item. If it is not highlighted, then highlight it and select [Next.]




Select [Browse].


Caution: Do not press [Download Latest Version]



Select [Desktop] from Drop-Down menu.




Highlight the Update File then select [Open].



Select [Next].

Choose the Update Method




If your PC is Bluetooth compatible or you have a Bluetooth dongle plugged into your computer, the screen on the left will be displayed.

Note: If this screen is not displayed, refer to the Troubleshooting Section in Part 4.


Highlight the “Bluetooth connection” option then select [Next].

Caution: Do not select the “Bluetooth virtual serial connection” option.

Searching for the Kenwood Audio Product to Update




Select [Search Devices] to display a list of Bluetooth-enabled device.



Highlight the product to be updated from the list then Select [Next].

Establishing the Bluetooth Connection



After Selecting the [Next] button the screen shown to the left will be displayed.

Click on the pop-up message that is displayed at the bottom right of your PC screen. Be sure to click the message portion; do not close it.



Entering the Passkey (PIN)



This prompt screen will automatically display on the PC to enter the Passkey.
Note 1: This is the same PIN you used to pair your phone with your Kenwood Audio Product. If you did not initiate a personal PIN, you can use the default. Default setting = 0000.

Note 2: If an Error occurs after entering the PIN, verify the PIN in the Bluetooth Menu Screen.

Note: Refer to the Trouble Shooting Instructions in Part 4.

Note: This Update Process will take approximately 2~3 minutes.
Do not Power Off the unit during the Update Procedure.



Update in Progress screen.





"Updating" will be displayed

Flash Update Successful Screens



Select [FINISH] to close the Parrot Software Update Wizard.


Note: The updating process on your Kenwood unit may take several minutes to complete even after you have finished the Flash Update process.



Press the [CLOSE] button to exit.

Press the [FNC] button to exit.

Verify the Bluetooth Software Update



Verify that SW Version 1.60 has been updated successfully in the Kenwood unit.
Audio Unit: [Standby] / [Menu] / [BT F/W UPDATE].

Your Kenwood unit now includes the necessary software update.